

### Instructions

- Fill out the container label including **name, date of birth, date/time of collection.**
- Affix completed name label to outer plastic vial.
- Open the outer vial and remove the inner sample vial. Leave the absorbent material in the outer vial.
- Put on disposable gloves. Lift the toilet seat.
- Unfold the EasySampler paper cutout and orient the larger flap towards the back of the toilet with the tape side down.
- Remove the protective covering from the taped flaps and adhere to the toilet, making sure the paper cutout forms the shape of a bowl. You may reorient the adhesive flaps if necessary.
- Put the toilet seat back down.
- Have a bowel movement. NOTE: Avoid contact with urine or toilet water.
- Unscrew the brown cap from the inner sample vial and using the EasySpoons, place several scoops of stool into the inner sample vial to fill at least halfway.
- Carefully screw the brown cap back on the inner sample vial making sure there is a tight seal. Place inside the outer vial. (Do NOT place stool in tissue or absorbent material).
- Flush remainder of the bowel movement.
- Place stool container into padded envelope.
- Place padded envelope into biohazard specimen bag.
- Complete the highlighted portion of the test requisition form (collection date).
- **Place completed test requisition into the paperwork slot in the biohazard bag.**
- Place biohazard bag containing test requisition and stool specimen into cardboard box.
- Place cardboard box into preaddressed/prepaid FedEx ClinPak mailing envelope.
- Remove EasySampler paper cutout from toilet, remove gloves and discard all in wastebasket.
- Wash hands to prevent contamination.

### Materials Included:

- 1 EasySampler paper cutout with adhesive strips
- 2 paper EasySpoons
- 1 pair of disposable gloves
- 1 leak proof sample tube/vial with plastic scoop embedded into brown screw cap
- 1 leak proof outer tube/vial with absorbent material and screw cap
- 1 padded envelope
- 1 container label
- 1 biohazard specimen bag
- 1 Test Requisition form
- 1 FedEx ClinPak mailing envelope affixed with a prepaid FedEx Airbill label

### FedEx Delivery Instructions

**Specimens must be collected and mailed (or dropped off) to FedEx ASAP.**

Call 1-800-GO-FEDEX to schedule a pick up, or drop the completed kit off at your nearest FedEx drop-off.

*Please send by end of day Thursday. Do NOT send on Friday or the weekend.  
\*Please complete this step ASAP to avoid having to repeat sample collection\**

Collection-related questions:  
941.757.4800 x307

# Visual Collection Instructions



## FAQ

### What is this kit for?

- This kit is **only** for the FilmArray test order. The FilmArray is a PCR test that detects gastrointestinal pathogens including viruses, bacteria and parasites that cause infectious diarrhea.

### I've collected my sample. What next?

- Call FedEx 1-800-GO-FEDEX (1-800-463-3339) to schedule a Pickup from your home or visit <https://local.fedex.com/en-us> to locate a FedEx drop off location near you.
- This should be done as soon as possible.

### I've collected my sample but I am waiting for FedEx. What do I do with my sample?

- The completed kit can be held at room temperature until handed off to FedEx.

### How do I get my results?

- Your gastroenterologist's office will call you with your results.

Collection-related questions:  
941.757.4800 x307